

Time Change

Panasonic KXTD-308

Panasonic KXTD-816

Panasonic KXTD-1232

This procedure must be done from the operator's or manager's phone.

Press **PROGRAM**

Dial * * **1 2 3 4 0 0 0**

Press **SPEAKERPHONE**

Press **SPEAKERPHONE** again

Enter the correct **Hour**

Press **FWD/DND**

Enter the correct **Minutes**

Press **FWD/DND**

Use the AutoAnswer button to select **AM** or **PM**

Press **AUTODIAL / STORE** to save

Lift and replace handset

Your Done!