

TIME CHANGE TOSHIBA CIX/CTX

Main Phone (ext 200 or the Operators Telephone)

Handset On Hook

Press Intercom (extension button)

Dial # 652

Enter Time in Military Time HH/MM/SS

Press #